



POWERED CHURCH TROLLEY

POWER Z501

MAIN FEATURES

- Lightweight, durable aluminum structure
- Lifting system with reel mechanism enables smooth and controlled coffin sliding
- Folds easily like an accordion
- Four pivoting wheels with 20 cm (7.9 in) diameter for better movement across uneven surface
- 2 locking brakes on the wheels
- Handles swivel outward - rotating 90° - to make transport easier
- It moves silently without making any noise.



PRODUCT DESCRIPTION: Crafted in Italy and available in bronze, silver, or black finishes, the Power Z501 church trolley blends robust durability with effortless usability. Its lightweight aluminum frame allows easy handling by a single operator, while stainless steel joints and handles provide superior strength and long-term reliability. All moving parts feature precision-lubricated nylon and Teflon rings, ensuring smooth, silent folding and unfolding. The trolley also includes an integrated tilting mechanism to accommodate ceremonial positioning when required.

INTENDED USE: Designed for dignified and efficient transportation of coffins within churches and funeral settings.

PRODUCT INCLUDES

- Battery 2Ah - 18V - Li-Ion
- Battery charger
- Remote control with cable



**BATTERY
POWERED**

661 lb
↔
300 kg

**LOAD
CAPACITY**






**ADJUSTABLE LIFTING
MECHANISM**



**EASY
SCROLLING**

TECHNICAL DATA

Code	ZC00900	ZC00901	ZC00902
Color			
Length	135,5 cm / 53.3 in	135,5 cm / 53.3 in	135,5 cm / 53.3 in
Width with handles folded	55 cm / 21.7 in	55 cm / 21.7 in	55 cm / 21.7 in
Width with handles extracted	100 cm / 39.4 in	100 cm / 39.4 in	100 cm / 39.4 in
Height with lifting system closed	61,1 cm / 24.1 in	61,1 cm / 24.1 in	61,1 cm / 24.1 in
Stroke of lifting system	Ø20 cm / Ø7.9 in	Ø20 cm / Ø7.9 in	Ø20 cm / Ø7.9 in
Dimensions folded	80 x 29 x 55 cm 31.5 x 11.4 x 21.7 in	80 x 29 x 55 cm 31.5 x 11.4 x 21.7 in	80 x 29 x 55 cm 31.5 x 11.4 x 21.7 in
Weight	24 kg / 52.9 lb	24 kg / 52.9 lb	24 kg / 52.9 lb
Remote control with cable	✓	✓	✓
Lifting speed	6 mm/s	6 mm/s	6 mm/s
Battery	2 Ah – 18V - Li-Ion	2 Ah – 18V - Li-Ion	2 Ah – 18V - Li-Ion
Battery charging time	~ 60 min	~ 60 min	~ 60 min
Wheels dimensions	Ø20 cm / Ø7.9 in	Ø20 cm / Ø7.9 in	Ø20 cm / Ø7.9 in
Brakes	4	4	4
Loading capacity	300 kg / 661 lb	300 kg / 661 lb	300 kg / 661 lb
Frame material	Aluminum	Aluminum	Aluminum

Note: Dimensions and weight are subject to tolerances of ± 1 cm and ± 0,2 kg respectively.



ADJUSTABLE LIFTING MECHANISM

With the push of a button, the lifting mechanism makes sure the truck is aligned with the vehicle's floor during the loading and offloading phases. This feature allows you to tilt the casket during funeral ceremonies.